

Box Contents



















Contenu de la boîte

Lieferumfang

Contenido de la caja

Contenuti della confezione

同梱物

<p>A</p> 	<p>B</p>  <p>24" / 61 cm</p>	<p>C (2)</p>  <p>36.2" / 92 cm</p>
<p>D1 (2)</p>  <p>D1= 28.25" / 72 cm</p>	<p>D2 (2)</p>  <p>D2= 32.50" / 83 cm</p>	<p>E</p>  <p>13.8" / 35 cm</p>
<p>F (9)</p> 	<p>G (4)</p> 	<p>H (4)</p> 
<p>I</p>  <p>タム 1 8" / 20 cm</p>	<p>J</p>  <p>タム 2 10" / 25 cm</p>	<p>K</p>  <p>タム 3 12" / 30 cm</p>
<p>L</p>  <p>タム 4 14" / 36 cm</p>	<p>M</p>  <p>スネア 14" / 36 cm</p>	<p>N</p>  <p>ハイハット(トップ) 14" / 36 cm</p>
<p>O (3)</p>  <p>クラッシュ 14" / 36 cm</p>	<p>P</p>  <p>ライド 16" / 41 cm</p>	<p>Q</p>  <p>キック 20" / 51 cm</p>

Box Contents














Contenu de la boîte

Lieferumfang

Contenido de la caja

Contenuti della confezione

同梱物

R 	S 	T 
U 	V 	W 
X 	Y (4) 	Z 
AA 	BB 	CC (16) 
DD 	EE (2) 